

Main data table with columns for station numbers (e.g., 001, 002, 003) and rows for various parameters. The table is organized into sections labeled '上段: 浸水深(m)' and '下段: [地盤高(T.P.M)]'. It contains a dense grid of numerical values.

凡例
上段:
浸水深(m)

2.11
[12.61]

下段:
[地盤高(T.P.M)]

0 25 50 75 100 m
地理院タイル